



Tips for Talking to Amazon Alexa

Use this device like you would use any other Alexa-Enabled device.

When talking to an Alexa-Enabled device, speak loudly and clearly without a pause.



SINGLE FUNCTION COMMANDS

Stop	"Amazon, turn off Odessa."
Head Up	"Amazon, turn on Odessa head up."
Head Down	"Amazon, turn on Odessa head down."
Foot Up	"Amazon, turn on Odessa foot up."
Foot Down	"Amazon, turn on Odessa foot down."
Elevate	"Amazon, turn on Odessa elevate."
Descend	"Amazon, turn on Odessa descend."
Neck Up	"Amazon, turn on Odessa neck up."
Neck Down	"Amazon, turn on Odessa neck down."

SLEEP ENHANCMENT COMMANDS

Sleep Wave 1	"Amazon, turn on Odessa sleep wave 1."
Sleep Wave 2	"Amazon, turn on Odessa sleep wave 2."
Sleep Wave 3	"Amazon, turn on Odessa sleep wave 3."
Sleep Intensity 1	"Amazon, turn on Odessa sleep intensity 1."
Sleep Intensity 2	"Amazon, turn on Odessa sleep intensity 2."
Sleep Intensity 3	"Amazon, turn on Odessa sleep intensity 3."
Sleep Time 10	"Amazon, turn on Odessa sleep time 10."
Sleep Time 20	"Amazon, turn on Odessa sleep time 20."
Sleep Time 30	"Amazon, turn on Odessa sleep time 30."
Sleep Off	"Amazon, turn off Odessa sleep."



ALEXA COMMANDS

2018 Wi-Fi Compatible Bases



Tips for Talking to Amazon Alexa

Use this device like you would use any other Alexa-Enabled device.

When talking to an Alexa-Enabled device, speak loudly and clearly without a pause.



MEMORY POSITION COMMANDS

Zero Gravity	"Amazon, turn on Odessa zero gravity."
Go Flat	"Amazon, turn on Odessa flat."
Anti-Snore	"Amazon, turn on Odessa anti-snore."
Bed Light On	"Amazon, turn on Odessa light."
Bed Light Off	"Amazon, turn off Odessa light."
Memory A	"Amazon, turn on Odessa memory A."
Memory B	"Amazon, turn on Odessa memory B."
Memory C	"Amazon, turn on Odessa memory C."
Memory A Head Up	"Amazon, turn on Odessa memory A head up."
Memory B Head Up	"Amazon, turn on Odessa memory B head up."
Memory C Head Up	"Amazon, turn on Odessa memory C head up."
Memory A Foot Up	"Amazon, turn on Odessa memory A foot up."
Memory B Foot Up	"Amazon, turn on Odessa memory B foot up."
Memory C Foot Up	"Amazon, turn on Odessa memory C foot up."
Memory A Neck Up	"Amazon, turn on Odessa memory A neck up."
Memory B Neck Up	"Amazon, turn on Odessa memory B neck up."
Memory C Neck Up	"Amazon, turn on Odessa memory C neck up."
Save Memory A	"Amazon, turn on Odessa save memory A."
Save Memory B	"Amazon, turn on Odessa save memory B."
Save Memory C	"Amazon, turn on Odessa save memory C."

